

Premium Stand Assembly Instructions

Assembling of Stand requires the 8 M6 x 15mm bolts provided



1

Using 8 bolts provided, attach the Top & Bottom Braces to the sides

